





- (1) When switching product type / when performing a routine check / when a defect occurs, insert a piece of Prescale, cut to the appropriate size, between the molds of the stacking machine.
- (2) Check the evenness of the Prescale's coloring to determine whether the pressure applied to the molds is uniform, whether there is any displacement or inclination, or uneven pressure between the molds.
- (3) If there is uneven pressure, adjust the machine and then insert another piece of Prescale to check the pressure balance once again.





Note that the specifications and performance data described in this catalog are subject to change without notice for the purpose of improvement. Since the images provided are used for illustration purposes, they may differ slightly from actual products.



Sensor Products Inc. 300 Madison Ave,Madison, NJ 07940 USA 1.800.755.2201 (Toll Free) sales@sensorprod.com

An authorized Fujifilm Prescale distributor in the U.S.A., Canada, Mexico and the Caribbean only.